

ALLKLEEN INDUSTRIAL

Heavy Duty Universal Cleaner & Degreaser

FEATURES

- MPI Approved C38 (All animal product except dairy)
- Non Flammable
- Readily miscible with water
- Unperfumed
- Spray on/Wipe off application
- Heavy duty capacity
- Effective in hard water
- Economical

AREAS OF USE

- Industrial - Ultrasonic Cleaning
- Mining
- Restaurants
- Takeaway Bars
- Hotels, Motels
- Hospitals
- Abattoirs, Freezing Works
- Garages & Service Stations

PHYSICAL & CHEMICAL PROPERTIES

Form	Liquid
Colour	Clear Red
Odour	Slight detergent smell
pH	>12.5
Specific Gravity	1.085

PRODUCT DETAILS

Item Code: 2033940
Pack Size: 5L

Item Code: 2033930
Pack Size: 20L

Item Code: 2033750
Pack Size: 200L

PRODUCT ENQUIRIES

Australia: 1800 148 791 info@techspan.com.au
New Zealand: (09) 827 6567 info@techspan.co.nz

DESCRIPTION

ALLKLEEN INDUSTRIAL : is an economical, heavy duty universal cleaner and degreaser. It is a clear red liquid and is specifically formulated for the effective removal of a variety of greases and fat even in extreme hard water conditions and it is ideal for cleaning in food preparation areas.

ALLKLEEN INDUSTRIAL : can be used for all heavy duty cleaning tasks where the surface is not adversely affected by alkalinity. It also removes other soils including mineral oils, waxes, built up soap deposits clays and carbon. Since it is water based it is an alternative to flammable solvent degreasers, particularly in areas of high fire and explosion risk.

ALLKLEEN INDUSTRIAL can be used on any washable surface such as:

- Floors & walls
- Baths & showers
- Tools & machinery
- Barbecues, grills, ovens, hotplates, deep fryers
- Exterior cladding & roofs
- Refrigerators
- Sinks & basins

DIRECTIONS FOR USE

Apply manually by wiping, mopping or brushing. (Can be used in ultrasonic cleaners , immersion in heated, aerated soak tanks.)

ALLKLEEN INDUSTRIAL will work in cold water but is most effective with a water temperature around 60 – 70°C. Aeration of immersion tanks will also improve cleaning. Use also for machine application steam cleaners, high-pressure sprayers and floor scrubbers with vacuum pick-up.

Dilution rates vary with soiling but typically:

- 1:10 - For heavy soiling, i.e. steam/pressure cleaners, degreasing etc.
- 1:40 – For floors, walls, glass, paintwork, tile and light degreasing.
- 1:60 - For light soiling i.e. kitchen and janitorial cleaning and painted surfaces etc.

SAFETY INFORMATION

- If poisoning occurs contact a doctor or Poisons Information Centre. Phone New Zealand 0800 764 766.
- If aspirated into the lungs, remove from exposure.
- If swallowed, do NOT induce vomiting, give water to drink and seek medical attention.
- If in eyes, hold eyes open, and flood for at least 15 minutes and see a doctor.
- If skin or hair contact occurs, remove contaminated clothing and wash skin thoroughly with water.

24 Hours Toll Free Emergency Phone NZL: 0800 764 766
24 Hours Toll Free Emergency Phone AUS: 1800 629 953

For further information regarding product safety and handling, refer to the Material Safety Data Sheet and Product Label.

TECHSPAN GROUP

Australia: Phone - 1800 148 791 email - info@techspan.com.au Website - www.techspan.com.au
New Zealand: Phone - (09) 827 6567 email - info@techspan.co.nz Website - www.techspan.co.nz